

ENCREURS




METAL LINE **NOUVEAU 4.0**

Référence	Pour appareils	Couleurs d'encre	Prix
6/4907	4907	A B C D E Z	
6/4910	4810, 4910, 4910TA, 4836	A B C D E Z	
6/4911	4800, 4820, 4822A, 4822B, 4822C, 4846, 4911, 4911T, 4951, 4991	A B C D E Z	
6/4911AT spécial textile	4800, 4820, 4822A, 4822B, 4822C, 4846, 4911, 4911T, 4951CM	AT	
6/4912	4912, 4912T, 4952, 4992	A B C D E Z	
6/4912/2	4912, 4912T, 4952	Cassette rouge avec pavé bleu de 15 mm	
6/4913	4913, 4913T, 4953	A B C D E Z	
6/4914	4914	A B C D E Z	
6/4915	4915	A B C D E Z	
6/4916	4916	A B C D E Z	
6/4918	4918	A B C D E Z	
6/4921	4921	A B C D E Z	
6/4922	4922	A B C D E Z	
6/4923	4923, 4930	A B C D E Z	
6/4923/20			
6/4924	4724, 4740, 4924, 4940	A B C D E Z	
6/4925	4925, 4925T	A B C D E Z	
6/4926	4926, 4726	A B C D E Z	
6/4926/2		Cassette exclusivement pour 4726	
6/4927	4727, 4927, 4957, 4927T, 4727T	A B C D E Z	
6/4927/2		Cassette exclusivement pour 4727	
6/4928	4928, 4958, 4928T	A B C D E Z	
6/4929	4929, 4729	A B C D E Z	
6/4929/2		Cassette exclusivement pour 4729	
6/4931	4931, 4731, 4931T	A B C D E Z	
6/4931/2		Cassette exclusivement pour 4731	
6/4612	4612	A B C D E Z	
6/46019	46019, 46119	A B C D E Z	
6/46025	46025, 46125	A B C D E Z	
6/4630	4630, 4630T	A B C D E Z	
6/46030	46130	A B C D E Z	
6/46030/2		Cassette exclusivement pour 46130	
6/46040	46140	A B C D E Z	
6/46040/2		Cassette exclusivement pour 46140	
6/46040/2R		Cassette exclusivement pour 46140	
6/4642	4642	A B C D E Z	
6/4642/2R		Cassette exclusivement pour 4642	
6/46045	46045, 46145, 46045T	A B C D E Z	
6/46045/2		Cassette exclusivement pour 46145	
6/44045	44045	A B C D E Z	
6/44055	44055	A B C D E Z	
6/4750	4941, 4750, 4750L1, 4750L2, 4750L8, 4755	A B C D E Z	
6/4750/2		Cassette exclusivement pour 4750L et 4755	
6/4817	4813, 4817A, 4817B, 48313, 4917, 4817C BL/BL 4817D R/R	A B C D E Z	
6/4850	4850, 4850L1, 4850L2, 4850L8	A B C D E Z	
6/4850/2		Cassette exclusivement pour 4850	

Référence	Pour appareils	Couleurs d'encre	Prix
6/15		A B C D E Z	
6/15/2	5215, 5415	Cassette exclusivement pour 5415	
6/15/2/30		Cassette exclusivement pour 5215	
6/50	5030, 5200, 5430, 5431, 5435, 5546	A B C D E Z	
6/50/2		Cassette exclusivement pour 5430, 5431, 5435	
6/53	5203, 5253, 5440	A B C D E Z	
6/53/2		Cassette exclusivement pour 5440, 5440/2	
6/55	5205	A B C D E Z	
6/56	5117, 5204, 5206, 5460, 5460L, 5465, 5558, 5558PL, 55510, 55510PL, 5466PL	A B C D E Z	
6/56/2		Cassette exclusivement pour 5460, 5460L, 5465	
6/57	5207, 5470	A B C D E Z	
6/57/2		Cassette exclusivement pour 5470	
6/58	5274, 5474, 5208, 5480, 55418	A B C D E Z	
6/58/2		Cassette exclusivement pour 5474 et 5480	
6/511	5211, 54110, 54110/2	A B C D E Z	
6/511/2		Cassette exclusivement pour 54110	
6/512	5212, 54120, 54120/2	A B C D E Z	
6/512/2			
6/52040	52040, 54140	A B C D E Z	
6/52040/2		Cassette exclusivement pour 54140	

> Remplacement de la cassette d'encre pour Metal Line 4.0



MOBILE PRINTY

Référence	Pour appareils	Couleurs d'encre	Prix
6/9411	9411	A B C D E	
6/9412	9412, 9412T	A B C D E	
6/9413	9413	A B C D E	
6/9425	9425	A B C D E	
6/9430	9430	A B C D E	
6/9440	9440	A B C D E	



> Remplacement de la cassette d'encre pour Printy 4.0

